


BT6730 Alpha | BT6730 Video



User manual

The document is concerning the following products:

915747	BT6730 Alpha 12P H10
915748	BT6730 Alpha 14P H10
915749	BT6730 Alpha 12P H15
915750	BT6730 Alpha 14P H15
915782	BT6730 Vidéo 7M 12P H10
915786	BT6730 Vidéo 7M 14P H10



BODET Time & Sport
1 rue du Général de Gaulle
49340 Trémontaines | France
Tel: +33 241 71 72 33



Réf: 607529 D

Upon receipt, always check the product for damage during shipment. If any is found, you may file a damage claim with the carrier.

Foreword

This manual presents the functionalities of the BT6730 type scoreboards: description of each display according to the sport practiced (list of the main sports played with one or more BT6730 scoreboards).

The use of these scoreboards is carried out from the Scorepad: refer to the the product manual.

Important

Use the Euroleague program only for the Euroleague Basketball matches and only with a BT6008 shot clock (the BT6002C shot clock does not display to the 1/10 of a second).

**Information about the operation of the keyboards in HF radio:
in order to limit disruptions due to 4G network we recommend that the mobile phones be kept away from the keyboards.**

Table des matières

Basketball	4
Handball	5
Volleyball	6
Tennis	7
Badminton	8
Training	9


Basketball




BT6730 Alpha 12P H10




BT6730 Alpha 14P H10




BT6730 Video 7M 12P H10



BT6730 Alpha 12P H15



BT6730 Alpha 14P H15




BT6730 Video 7M 14P H10

Designation	Index
Minute-second timer (1/10 of a second display in the last minute). Countdown of intervals of play. Local time.	A
Timer stopped indicator.	B
Period number (E for extra time).	C
Scores from 0 to 999 HOME/VISIT.	D and D'
Team fouls HOME/VISIT. Reset to zero between the game periods.	E and E'
3 time out indicators HOME/VISIT (flashing during time out countdown). Reset to zero between the game periods.	F and F'
Players numbers and names.	G and G'
Team names.	H and H'
Brief display of last player foul HOME/VISIT (player's number/number of fouls).	I and I'
Time out countdown HOME/VISIT.	J and J'
Player fouls and points HOME/VISIT.	K and K'
Possession time countdown. 1/10 of a second display in the last second.	N
Score per player.	P and P'
Brief display of last player foul HOME/VISIT (player's number/number of fouls).	Q and Q'
Brief display of last player foul HOME/VISIT (player's number/number of fouls).	R and R'
Brief display of last player foul HOME/VISIT (player's number/number of fouls) or time-out countdown	S and S'

Handball




BT6730 Alpha 12P H10



BT6730 Alpha 12P H15




BT6730 Alpha 14P H10



BT6730 Alpha 14P H15



BT6730 Video 7M 12P H10



BT6730 Video 7M 14P H10

Designation	Index
Minute-second timer. Countdown of intervals of play. Local time	A
Timer stopped indicator.	B
Period number (E for extra time).	C
Scores from 0 to 999 HOME/VISIT.	D and D'
Number of penalties. 1 dash by penalty.	E and E'
3 time out indicators HOME/VISIT (flashing during time out countdown). Reset to zero between the game periods.	F and F'
Team names.	H and H'
First penalty countdown HOME/VISIT.	I and I'
Second penalty countdown HOME/VISIT.	J and J'
Unused	P and P'
First penalty countdown with player number HOME/VISIT.	Q and Q'
Second penalty countdown with player number HOME/VISIT.	R and R'
Third penalty countdown with player number HOME/VISIT.	S and S'

(*) Even if the scoreboard cannot display the penalty countdown the information is visible on the keyboard.


Volleyball




BT6730 Alpha 12P H10




BT6730 Alpha 14P H10




BT6730 Video 7M 12P H10



BT6730 Alpha 12P H15



BT6730 Alpha 14P H15



BT6730 Video 7M 14P H10

Designation	Index
Number of sets won or countdown of intervals of play or countdown of time outs.	A
Unused.	B
Number of the set under way.	C
Scores and service indicator HOME/VISIT.	D and D'
Number of sets won. Information displayed during an rest time or a time out.	E and E'
3 free time out indicators HOME/VISIT (flashing during time out countdown). Reset to zero between the game periods. Technical time outs are not displayed.	F and F'
Team names.	H and H'
Results of previous sets HOME/VISIT.	I and I'
Results of previous sets HOME/VISIT.	J and J'
Unused.	K and K'
Unused.	P and P'
Results of previous sets HOME/VISIT.	Q and Q'
Results of previous sets HOME/VISIT.	R and R'
Results of previous sets HOME/VISIT.	S and S'

Tennis




BT6730 Alpha 12P H10



BT6730 Alpha 12P H15




BT6730 Alpha 14P H10



BT6730 Alpha 14P H15



BT6730 Video 7M 12P H10




BT6730 Video 7M 14P H10

Designation	Index
Number of sets won.	A
Unused.	B
Number of the set under way.	C
Points of the current game HOME/VISIT. Service indicator HOME/VISIT.	D and D'
Number of sets won HOME/VISIT.	E and E'
Unused.	F and F'
Players' names.	H and H'
Results of previous sets HOME/VISIT.	I and I'
Results of previous sets HOME/VISIT.	J and J'
Unused.	K and K'
Unused.	P and P'
Results of previous sets HOME/VISIT.	Q and Q'
Results of previous sets HOME/VISIT.	R and R'
Results of previous sets HOME/VISIT.	S and S'


Badminton




BT6730 Alpha 12P H10



BT6730 Alpha 12P H15




BT6730 Alpha 14P H10



BT6730 Alpha 14P H15



BT6730 Video 7M 12P H10



BT6730 Video 7M 14P H10

Designation	Index
Number of winning sets or rest time or playing time.	A
Unused.	B
Number of the current set 1 to 5.	C
Points current set LOC/VISIT. Service indicator LOC/VISIT.	D and D'
Number of winning set LOC/VISIT.	E and E'
Extra time 1 or 3 points.	F and F'
Players' names.	H and H'
Results of previous sets HOME/VISIT.	I and I'
Results of previous sets HOME/VISIT.	J and J'
Unused.	K and K'
Unused.	P and P'
Results of previous sets HOME/VISIT.	Q and Q'
Results of previous sets HOME/VISIT.	R and R'
Results of previous sets HOME/VISIT.	S and S'


Training




BT6730 Alpha 12P H10




BT6730 Alpha 14P H10




BT6730 Video 7M 12P H10



BT6730 Alpha 12P H15



BT6730 Alpha 14P H15



BT6730 Video 7M 14P H10

Designation	Index
Sequence or rest time timer.	A
Timer stopped indicator.	B
Unused.	C
Number of sequence remaining to play (D) and number of sequence programmed (D').	D and D'
Unused.	E and E'
Unused.	F and F'
Unused.	H and H'
Unused.	I and I'
Unused.	J and J'
Unused.	K and K'
Unused.	P and P'
Unused.	Q and Q'
Unused.	R and R'
Unused.	S and S'