


BODET Scorepad



User manual - Tennis

For software version V1.1B01



www.bodet-sport.com

BODET SA
BP30001
49340 Trémentines | FRANCE
Tel: +33 (0)2 41 71 72 98
Fax: +33 (0)2 41 71 72 01



Ref.: 607955 A

Ensure on delivery that the product has not been damaged in transport.

1. Tennis

1) Select




2) Select a configuration from the list:

- 5 SET TENNIS
- 3 SET TENNIS
- 5 SET TENNIS without tie break
- 3 SET TENNIS without tie break


Configurations identified by can only be edited with the club access code. The club Access code is "1234". It can be changed in the "Club access" menu.

3) Screen in 5 SET TENNIS match mode:




Pressing a game setting brings up a new window in which you can:

- 1 assign the serve to a player.
- 2 edit name of player. After pressing LOCALS or VISITORS, press Config. team to edit the configuration of the teams (edit team screen name, activate players, choice of colours, load a team, create a new team or delete a team):



- 3 display sets. Press once to correct the results of sets or to delete the last set.
- 4 correct points in current set.
- 5 add a point to player (15, 30, 40 or Advantage).
- 6 edit the configuration settings (see next page for the list of settings).
- 7 start a new match. **Caution: the match in progress will be lost.**

> ENTERING CONFIGURATION SETTINGS

1) Click  to edit a configuration. The list of editable settings is given below:

Note: All these settings are accessible from the  **Advanced Settings** menu.

The list of editable settings is given below:

Headings	Settings	Default values	Description	Standard settings
Match				
	Singles / Doubles	Singles	Singles or Doubles	√
	Number of sets won	2	1 to 3 sets	√
	Nb of games (per set)	6	1 to 9 games	√
	Tie-break	7	Function enabled using the ON/OFF button 1 to 20 points	√
	Super tie-break	OFF	Function enabled using the ON/OFF button 1 to 20 points	√
	Advantage	ON	Function enabled using the ON/OFF button	√
	Game without point	OFF	Function enabled using the ON/OFF button	√
Miscellaneous				
	Maintain result	20s	1 to 99 seconds in steps of 1	-
HDMI				
	Load image	ON	Enabling wallpaper image (if OFF = wallpaper black)	-
Function keys				
	Alpha message	OFF	Function enabled using the ON/OFF button	-
	Set won	ON	Function enabled using the ON/OFF button	√
	Match won	ON	Function enabled using the ON/OFF button	√
	Category	ON	Function enabled using the ON/OFF button	√