

# BODET Scorepad



## User manual - Badminton



[www.bodet-sport.com](http://www.bodet-sport.com)

**BODET SA**  
BP30001  
49340 Trémentines | France  
Tel: +33 (0)2 41 71 72 98  
Fax: +33 (0)2 41 71 72 01



Ref.: 607959 A

*Ensure on delivery that the product has not been damaged in transport.*


# 1. Badminton

1) Select




2) Select a configuration from the list:


- 1 set of 21 BADMINTON 
- 2 set of 15 BADMINTON 
- 3 set of 11 BADMINTON 


Configurations identified by  can only be edited with the club access code. The club Access code is "1234". It can be changed in the "Club access" menu.

3) Screen in 3 sets of 11 BADMINTON match mode:



Pressing a game setting brings up a new window in which you can:


- 1 assign the serve to a player.
- 2 edit name of player. After pressing LOCALS or VISITORS, press  Config. team to edit the configuration of the teams (edit team screen name, activate players, choice of colours, load a team, create a new team or delete a team):



- 3 display sets. Press once to correct the results of sets or to delete the last set.
- 4 correct points in current set.
- 5 edit the configuration settings (see next page for the list of settings).
- 6 start a new match. **Caution: the match in progress will be lost.**

## > ENTERING CONFIGURATION SETTINGS

1) Click  to edit a configuration.

**Note** : All these settings are accessible from the  **Advanced Settings** menu.

The list of editable settings is given below (e.g.: 3 set of 11 points) :

Headings	Settings	Default values	Description	Standard settings
<b>Match</b>				
	Singles / Doubles	Singles	Singles or Doubles	√
	Number of sets won	3	1 to 3 sets	√
	Nb of games (per set)	11	1 to 11 games	√
	Points spread	2	-	√
	Marking continues	ON	Function enabled using the ON/OFF button	-
<b>Display</b>				
	Set time-out	60s 11pts	Function enabled using the ON/OFF button 1 to 60 points in steps of 1 0 to 5 minutes in steps of 1 0 to 59 seconds in steps of 1	-
	Match/set duration	ON	Display of the match duration for every set Function enabled using the ON/OFF button	-
	Set pause	120s	-	-
<b>Miscellaneous</b>				
	Maintain result	1s	1 to 99 seconds in steps of 1	√
<b>HDMI</b>				
	Logo partner	OFF	Function enabled using the ON/OFF button	-
	Wallpapers	ON	Function enabled using the ON/OFF button	-
<b>Function keys</b>				
	Match/set won	OFF	Function enabled using the ON/OFF button	-
	Category	OFF	Function enabled using the ON/OFF button	-