

BODET SCOREPAD



User Manual - Rink hockey



www.bodet-sport.com

BODET Time & Sport
1 rue du Général de Gaulle
49340 Trémentines | France
Tel: +33 (0)2 41 71 72 33



Réf.: 608109 B


Ensure on delivery that the product has not been damaged in transport.

1. Rink hockey

1) Select  on the home screen.

2) Select a configuration from the list:

- RINK HOCKEY 1 National 
- RINK HOCKEY 2 
- RINK HOCKEY 3 
- RINK HOCKEY 4 
- RINK HOCKEY 5 
- RINK HOCKEY 6 


Configurations identified by  can only be edited with the club code.


The club Access code is "1234". It can be changed in the "Club access" menu.



3) Screen in RINK HOCKEY 2x30 min match mode:



Pressing a game setting brings up a new window in which you can:

- 1 edit the length: duration of each period. The buzzer can be triggered at each end of period and the timer reset.
- 2 edit colour of team shirts and game markings. A standard colour scheme is provided as well as a palette to set your own colour.
- 3 edit the name of the team. After pressing LOCALS or VISITORS, press  **Config. team** to edit the configuration of the teams (edit team screen name, activate players, choice of colours, load a team, create a new team or delete a team):



4 call a time-out. To start the countdown, press the **START**  button. Add or delete a time-out by pressing **Correction** .

5 modify a point from the team score.


6 assign a penalty to a player or to the team.

List of the penalties for the player:

- > Minor: 2-minute penalty.
- > Major: 4-minute penalty.
- > Minor + Minor: 2-minute penalty + 2 minute.


List of the penalties for the team:

- > Minor bench: 2-minute penalty.
- > Major bench: 4-minute penalty.
- > Minor bench + minor bench : 2-minute penalty + 2 minute.



7 modify a point from the team score.

8 display/modify/delete one or more penalties in progress.



9 add a goal.


10 edit the configuration settings (see next page for the list of settings).

11 go to the next period.

12 start a new match. **Warning: the match in progress will be lost.**

> ENTERING CONFIGURATION SETTINGS

1) Click  to edit a configuration.

Note : All these settings are accessible from the  **Advanced Settings** menu.

The list of editable settings is given below:

Rink hockey	RINK HOCKEY 3	RINK HOCKEY 6	RINK HOCKEY 1 National	RINK HOCKEY 4	RINK HOCKEY 2	RINK HOCKEY 5
Before match						
Horn before match						
Horn before match	OFF	3m	OFF	3m	OFF	OFF
Horn before match	OFF	1m	OFF	1m	OFF	OFF
Pre-match duration	OFF	60m	OFF	60m	OFF	OFF
Match						
Period number	2	2	2	2	2	2
Period duration	30:00	20:00	10:00	30:00	15:00	25:00
End period Horn	5s	5s	5s	5s	5s	5s
Show stopwatch instant game	ON	ON	ON	ON	ON	ON
Overtime						
Overtime number	2	2	2	2	2	2
Overtime duration	10:00	10:00	2:30	10:00	10:00	10:00
Rest time	2:00	2:00	2:00	2:00	2:00	2:00
Rest time duration						
Half time horn						
Horn duration at end period	OFF	OFF	OFF	OFF	OFF	OFF
Horn N°1 before end	OFF	OFF	OFF	OFF	OFF	OFF
Inter period horn						
Horn duration at end period	OFF	OFF	OFF	OFF	OFF	OFF
Horn N°1 before end	OFF	OFF	OFF	OFF	OFF	OFF
Half time duration	15:00	15:00	15:00	15:00	15:00	15:00
Inter period duration	2:00	2:00	2:00	2:00	2:00	2:00
Duration before overtime	2:00	2:00	2:00	2:00	2:00	2:00
Possession						
Possession duration	45s	45s	24s	45s	45s	45s
Attack time	OFF	OFF	14s	OFF	OFF	OFF
Horn	3s	3s	3s	3s	3s	3s
Possession auto start	OFF	OFF	OFF	OFF	OFF	OFF
Timer auto stop	OFF	OFF	OFF	OFF	OFF	OFF
Display keyboard	ON	ON	ON	ON	ON	ON
Time-Out						
TO dots						
Number of TO dots	1	1	1	1	1	1
Reset Time-out	Half time	Half time	Half time	Half time	Half time	Half time

Duration TO	60s	60s	60s	60s	60s	60s
Horn TO						
Horn duration before end T-O	10s	10s	10s	10s	10s	10s
Horn end T-O	ON	ON	ON	ON	ON	ON
Horn at start	ON	ON	ON	ON	ON	ON
Duration short TO	30s	30s	30s	30s	30s	30s
Points and Fouls						
Total team fouls						
Total fouls	5	5	5	5	5	5
Reset total fouls	2	2	2	2	2	2
Points per player	OFF	OFF	OFF	OFF	OFF	OFF
Cards and penalties						
Activation of penalties	ON	ON	ON	ON	ON	ON
Blue card time	2:00	2:00	2:00	2:00	2:00	2:00
Red card time	4:00	4:00	4:00	4:00	4:00	4:00
Display player number	OFF	OFF	OFF	OFF	OFF	OFF
End penalty horn	OFF	OFF	OFF	OFF	OFF	OFF
Nb simultaneous penalties	3	3	3	3	3	3
Various						
Beeper buttons	ON	ON	ON	ON	ON	ON
Statistic software	OFF	OFF	OFF	OFF	OFF	OFF
Maintain result	10s	10s	10s	10s	10s	10s
HDMI						
HDMI display
Sponsors logo
Wallpaper
Team logo	ON	ON	ON	ON	ON	ON
Display penalties	ON	ON	ON	ON	ON	ON

Below is an explanation of each parameter:

Rink hockey	Comments
Before match	
Horn before match	
Horn before match	Choose the before-match duration at which the horn sounds
Horn before match	Choose the before-match duration at which the horn sounds
Pre-match duration	Choose the before-match duration.
Game	
Period number	Choose the number of periods
Period duration:	Choose the number of periods
End of period horn	Choose the duration of the horn when the game period is over
Display game clock	Function enabled using the ON/OFF button
Extra time	
Extra time number	Choose the extra time number

Extra time duration	Choose the duration of extra time
Rest time	Choose the duration of rest time.
Rest time duration	
Half-time horn	
Horn duration at end period	Select the duration of the horn before the end of each half time.
Horn N°1 before end	Horn before the end of Half time
Inter-period horn	
Horn duration at end period	Choose the duration of the horn before the end of each inter-period
Horn N°1 before end	Horn before the end of the inter-period time
Half-time duration	Choose the duration of half time
Duration between periods	Choose the duration of the inter-period time
Duration before extra time	Choose the duration before the extra time
Possession	
Possession time	Choose the duration of time possession
Attack time	Choose the duration of attack time
Buzzer	Choose the duration of the horn
Start possession auto.	Function enabled using the ON/OFF button
Stop time auto.	Function enabled using the ON/OFF button
Display keyboard	Function enabled using the ON/OFF button
Time-out	
TO dots	
Number of TO dots	Select the number of time out dots
Reset Time-out	Reset time outs at half time or between each period
Duration TO	Select the duration of each time out
Horn TO	
Horn duration before end T-O	Select the duration of the horn at the end of each time out.
Horn end T-O	Function enabled using the ON/OFF button
Horn at start	Function enabled using the ON/OFF button
Short T-O duration	Choose the duration of the short time out
Points and Fouls	
Total team fouls	
Total fouls	Function enabled using the ON/OFF button Select the period for the total team fouls reset Select the number for the total team fouls
Points per player	Function enabled using the ON/OFF button
Cards and penalties	
Activation penalties	Function enabled using the ON/OFF button
Blue card time	Select the duration of the blue card
Red card time	Select the duration of the red card
Display player number	Function enabled using the ON/OFF button
End of penalty buzzer	Function enabled using the ON/OFF button
No. simultaneous penalties	Function enabled using the ON/OFF button Select the number of simultaneous penalties

Miscellaneous	
Beeper buttons	Function enabled using the ON/OFF button
Statistical software	Function enabled using the ON/OFF button
Maintain result	Function enabled using the ON/OFF button Choose the display duration in seconds
HDMI	
HDMI display	Select HDMI display mode
Sponsor logos	Choose the sponsor logos to display
Wallpaper	Select the wallpaper for HDMI display
Team logos	Function enabled using the ON/OFF button Choose the teams logo display
Display penalties	Function enabled using the ON/OFF button