

# BODET Scorepad



## User Manual - Netball



[www.bodet-sport.com](http://www.bodet-sport.com)

**BODET SA**  
1 rue du Général de Gaulle  
49340 Trémentines | France  
Tel: +33 (0)2 41 71 72 99  
Fax: +33 (0)2 41 71 72 01




Ref.: 608284 A

*Ensure on delivery that the product has not been damaged in transport.*

# 1. Netball

1) Select  on the home screen.

2) Select a configuration from the list:

**NETBALL National** (Number period: 4 - Time period: 15:00 - Minor penalty: 2:00) 


**NETBALL 1** (Number period: 2 - Time period: 20:00 - Minor penalty: 2:00) 

**NETBALL 2** (Number period: 4 - Time period: 10:00 - Minor penalty: 2:00) 


Configurations identified by  can only be edited with the club code.


The club Access code is “1234”. It can be changed in the “Club access” menu.



3) Screen in NETBALL NATIONAL match mode:




Pressing a game setting brings up a new window in which you can:

- 1 edit the length : duration of each period. The buzzer can be triggered at each end of period and the timer reset.
- 2 edit colour of team shirts and game markings. A standard colour scheme is provided as well as a palette to set your own colour.
- 3 edit the name of the team. After pressing HOME or VISITORS, press  **Team config**. to edit the configuration of both teams (switch teams, edit team screen name, activate players, choice of colours, load configuration, create a new configuration or delete this configuration):



4 call a time-out. To start the countdown, press the **START**  button. Add or delete a time-out by pressing **Correction** .

5 award a penalty to a player:  
> Minor: 2-minute penalty.



6 modify a point from the team score.

7 display/modify/delete one or more penalties in progress.



8 add a goal.

9 edit the configuration settings (see next page for the list of settings).

10 add and then start a scrolling message.

11 move on to the next period.

12 start a new match. **Warning: the match in progress will be lost.**

## > ENTERING CONFIGURATION SETTINGS

1) Click  to edit a configuration.

**Note** : All these settings are accessible from the  **Advanced Settings** menu.

The list of editable settings is given below:

Headings	Settings	Default values	Description	Standard settings
<b>Before match</b>				
	Buzzer before match	OFF OFF	Activation of the pre-end horn with the ON/OFF key 1 to 5 minutes in steps of 1 0 to 59 seconds in steps of 1 Activation of the 2nd horn of end with the ON/OFF key	√
	Before match duration	OFF	Function enabled using the ON/OFF button 1 to 180 minutes in steps of 1	√
<b>Match</b>				
	Period number	4	1 to 9 periods in steps of 1	√
	Period time	15:00	1 to 90 minutes in steps of 1 0 to 59 seconds in steps of 1	√
	Period mode	Down	Count-up or countdown	√
	End of period buzzer	5 s	Function enabled using the ON/OFF button 0 to 9 seconds in steps of 1	√
<b>Extra time</b>				
	Extra time number	2	Function enabled using the ON/OFF button 1 to 9 periods in steps of 1	√
	Extra time duration	7:00	1 to 99 minutes in steps of 1 0 to 59 seconds in steps of 1	√
	Time-out	4:00	Function enabled using the ON/OFF button 1 to 90 minutes in steps of 1 0 to 59 seconds in steps of 1	√
<b>Time-out</b>				
	Time-out buzzer	OFF OFF	Buzzer duration to call a time-out 1 to 20 seconds in steps of 1	√
	Time before overtime	2:00	0 to 10 minutes in steps of 1 1 to 59 seconds in steps of 1	√
	Half-time	15:00	Function enabled using the ON/OFF button 0 to 90 minutes in steps of 1 0 to 59 seconds in steps of 1	√
	Inter-period time	4:00	Function enabled using the ON/OFF button 0 to 9 minutes in steps of 1 1 to 59 seconds in steps of 1	√
<b>Points and fouls</b>				
	Activation penalties	ON	Function enabled using the ON/OFF button	√
	Penalty minor	2:00	1 to 9 minutes in steps of 1 0 to 59 seconds in steps of 1	√
	Display player no.	OFF	Function enabled using the ON/OFF button	√
	End of penalty buzzer	OFF	Function enabled using the ON/OFF button	√
	Points per player	OFF	Function enabled using the ON/OFF button	√
	Selection mode	List of players	List of players or keyboard	√
<b>Time-out</b>				
	Plot T-O	30s Nb:1 half-time	Function enabled using the ON/OFF button 1 to 6 plots de temps mort 0 or 1 minute 1 to 59 seconds in steps of 1 Reset the dead time by period, half-time or deactivation of the reset function	√
	Buzzer T-O	10s OFF	Activation of the pre-end horn with the ON/OFF key 1 to 20 seconds in steps of 1 1 to 59 seconds in steps of 1 Buzzer can be triggered for end of time-out	√

<b>HDMI</b>				
	Logo partner	OFF	Function enabled using the ON/OFF button	√
	Load image	ON	Function enabled using the ON/OFF button	√
<b>Function keys</b>				
	Alpha message	ON	Function enabled using the ON/OFF button	√
	Next period	ON	Function enabled using the ON/OFF button	√